

CHOOSE YOUR BAND SIZE


CHOOSE YOUR CUP SIZE

SIZE	32	34	36	38	40	42	44	46	48
AA	S	S	S	M	M	M	L	L	L
A	S	S	S	M	M	M	L	L	L
B	S	S	M	M	M	L	L	L	XL
C	S	S	M	M	M	L	L	L	XL
D	S	M	M	M	L	L	L	XL	XL
DD/E	S	M	M	M	L	L	L	XL	XL
DDD/EE/F	M	M	M	L	L	L	XL	XL	XL
EEE/FF/G	M	M	M	L	L	L	XL	XL	XL
H	M	M	L	L	L	XL	XL	XL	XL

GENERAL SIZE CHART

SIZE	SPACING
S	3 ¹ / ₄ " to 8 ¹ / ₄ "
M	4" to 9"
L	5 ¹ / ₄ " to 10 ¹ / ₄ "
XL	6 ¹ / ₂ " to 11 ¹ / ₂ "

*Flange openings are approximately 2¹/₂" wide, the range reflects the distance from outside to inside points.



Measure from nipple to nipple

FLANGE OPENING SPACING CHART

SPACING	SIZE
32" - 37"	S
38" - 43"	M
44" - 49"	L
50" - 56"	XL

OVERBUST MEASUREMENT CHART